


BMBPD915



NO	Part Description	Factory Code
1	CHASSIS	-
2	FOOTPLATE	YSC-KNX.BP-LZ-0025
3	ALUMINUM LABEL	M.AKS-ETK-ALM-022
4	BAKALITE HANDLE	JP.M.AKS-KLP-BKL-022
5	FOULING COVER SHEET	YSC-KNX.BP-LZ-0180
6	BOTTOM COVER WEIGHT SHAFT	YTL-KNX.BP-KS-0009
7	BOTTOM COVER SKID PLATE	YSC-KNX.BP-LZ-0159
8	COVER DRIVE SHAFT	YTL-KNX.BP-KS-0007
9	UPPER COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0004
10	UPPER COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0003
11	BOTTOM COVER	ARA-KNX.BP-D-0004
12	TOP COVER HANDLE	YBR-KNX.BP-KS-0001
13	BOTTOM COVER SHAFT	YTL-KNX.BP-KS-0017
14	TOP COVER SHAFT	YTL-KNX.BP-KS-0021
15	UPPER COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0003
16	UPPER COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0004
17	TOP COVER SPRING BINDING SPACER SHEET	YSC-KNX.BP-LZ-0039
18	TOP COVER SPRING RETAINER BUSHING	YTL-KNX.BP-KS-0010
19	TOP COVER SPRING BINDING SPACER SHEET SCREW	YTL-KNX.BP-KS-0011
20	TOP COVER SHAFT FIXING BUSHING	YTL-KNX.BP-KS-0005
21	TOP COVER SPRING RETAINER WASHER	YSC-KNX.BP-LZ-0014
22	INJECTOR BULL	YTL-KNX.BP-KS-0013
23	BURNER INJECTOR BOLT	YTL-KNX.BP-KS-0016
24	NATURAL GAS PIPE	M.AKS-DKM-BP-001
25	3/4 BLACK CONICAL FITTING	M.MEK-TES-SYH-FTN-005
26	BURNER GAS ADJUSTMENT BUSHING	YTL-KNX.BP-KS-0015
27	INJECTOR	YTL-KNX.BP-KS-0014
28	FAHRENHEIT DIAL BUTTON	M.AKS-DGM-EMP-051
29	GAS THERMOSTAT	JP.M.ELK-MEK-TRM1-016
30	GAS BLOCK	M.GAZ-BLK-AB007-001
31	BOTTOM BURNER INSULATION SHEET	YSC-KNX.BP-LZ-0011
32	INNER STONE SUPPORT SHEET	YSC-KNX.BP-LZ-0140
33	INNER STONE SUPPORT LAY 896mm 50x50x5	YLS-KNX.BP-KS-0004
34	STONE (910*457*40)	M.TAS-FRN-BP-003
35	0-500 DEGREES FAHRENHEIT	JP.M.ELK-EDM-DGT-015
36	LEFT FRONT SHAFT	YSC-KNX.BP-LZ-0186
37	METAL LABEL	M.AKS-OZL-MTL-006
38	FRONT PANEL COVER SHEET	YSC-KNX.BP-LZ-0053
39	PULLER HANDLE	M.AKS-KLP-INX-001
40	TOP COVER	ARA-KNX.BP-D-0003
41	THERMOPILE	M.GAZ-TRL-009
42	THERMOPILE LIGHTER SET (B6H6D)	M.GAZ-PLT-PLC-009
43	GAS DEDANTOR	M.GAZ-TES-DTN-009