




BMBPEB125

NO	Part Description	Factory Code
1	126122 208V-750W RESISTANCE	M.ELK-RZS-BRU-BPE-001
2	CHASSIS	-
3	THERMOSTAT HOUSING SHEET	YSC-KNX.EPZ-PN-0218
4	STONE (910x610)	M.TAS-FRN-BP-001
5	FOOT SHEET	YSC-KNX.BP-LZ-0025
6	COVER DRIVE SHAFT	YTL-KNX.BP-KS-0007
7	COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0003
8	UPPER COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0004
9	PUL	YSC-KNX.BP-LZ-0016
10	UPPER COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0004
11	COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0003
12	COVER SHAFT	YTL-KNX.BPE-KS-0001
13	COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0003
14	UPPER COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0004
15	BUSHING HOLDING WASHER	YSC-KNX.BP-LZ-0018
16	SPRING HOLDER BUSHING	YTL-KNX.BP-KS-0010
17	SPRING BINDING SPACER	YTL-KNX.BP-KS-0011
18	LEFT FRONT SHAFT	YSC-KNX.BPE-LZ-0006
19	TAG	M.AKS-ETK-ALM-021
20	COVER SPRING	M.YAY-BP-001
21	RAKOR	JP.M.ELK-RKR-PLS-008
22	DEGREES FAHRENHEIT	JP.M.ELK-EDM-DGT-015
23	572 DEGREE LIMITER	M.ELK-MEK-LMT-018
24	85-450 SINGLE-PHASE THERMOSTAT	M.ELK-MEK-TRM1-002
25	RED SIGNAL LIGHT 110V	M.ELK-LMB-SNY-011
26	OVEN BUTTON	JP.M.AKS-DGM-MUH-005
27	BUTTON SOCKET	M.AKS-DGM-SKT-004
28	TIME CLOCK	JP.M.ELK-MEK-MTM-004
29	(0-1) SWITCH	M.ELK-SLT-KRS-005
30	KULP	JP.M.AKS-KLP-BKL-022
31	COVER	ARA-KNX.BP-EB-0002
32	METAL LABEL	M.AKS-OZL-MTL-006
33	COVER HANDLE	YBR-KNX.BPE-KS-0002