




BMBPEB915

NO		
1	126121 208V-600 W RESISTANCE	M.ELK-RZS-BRU-BPE-003
2	CHASSIS	-
3	THERMOSTAT HOUSING SHEET	YSC-KNX.EPZ-PN-0218
4	STONE (910*457*40)	M.TAS-FRN-BP-003
5	FOOT STICK	YSC-KNX.BP-LZ-0025
6	COVER DRIVE SHAFT	YTL-KNX.BP-KS-0007
7	COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0003
8	UPPER COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0004
9	COVER	ARA-KNX.BP-EB-0001
10	COVER HANDLE	YBR-KNX.BPE-KS-0004
11	PUL	YSC-KNX.BP-LZ-0016
12	UPPER COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0004
13	COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0003
14	COVER SHAFT	YTL-KNX.BPE-KS-0001
15	COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0003
16	UPPER COVER SHAFT LOWER BUSHING	YTL-KNX.BP-KS-0004
17	BUSHING HOLDING WASHER	YSC-KNX.BP-LZ-0018
18	SPRING HOLDER BUSHING	YTL-KNX.BP-KS-0010
19	SPRING BINDING SPACER	YTL-KNX.BP-KS-0011
20	LEFT FRONT SHAFT	YSC-KNX.BPE-LZ-0006
21	TAG	M.AKS-ETK-ALM-021
22	COVER SPRING	M.YAY-BP-001
23	RAKOR	JP.M.ELK-RKR-PLS-008
24	DEGREES FAHRENHEIT	JP.M.ELK-EDM-DGT-015
25	572 DEGREE LIMITER	M.ELK-MEK-LMT-018
26	85-450 SINGLE-PHASE THERMOSTAT	M.ELK-MEK-TRM1-002
27	RED SIGNAL LIGHT 110V	M.ELK-LMB-SNY-011
28	OVEN BUTTON	JP.M.AKS-DGM-MUH-005
29	BUTTON SOCKET	M.AKS-DGM-SKT-002
30	TIME CLOCK	JP.M.ELK-MEK-MTM-004
31	(0-1) SWITCH	M.ELK-SLT-KRS-005
32	KULP	JP.M.AKS-KLP-BKL-022
33	METAL LABEL	M.AKS-OZL-MTL-006