

BMCRS01 / BMCRS02 PARTS LIST & BREAKDOWN

BakeMax Part #	Part Description	BakeMax Part #	Part Description
1 - CRS01/06/001	Key	2 - CRS01/06/002	Right Drive Shaft
3 - CRS01/06/003	Bearing 6004ZZ	4 - CRS01/06/004	Bearing Block
5 - CRS01/06/005	Left Drive Shaft	6 - CRS01/06/006	Sprocket 26T
7 - CRS01/06/007	Sprocket 15T	8 - CRS01/06/008	Locking Bearing FC-20
9 - CRS01/06/009	Bearing 6002ZZ	10 - CRS01/06/010	C. Retainer Ring S-15
11 - CRS01/06/011	Stay	12 - CRS01/06/012	Sprocket 23T
13 - CRS01/06/013	Worm Spline	14 - CRS01/06/014	Double Worm Gear 24T
15 - CRS01/06/015	Sprocket 23T	16 - CRS01/06/016	Spacer
17 - CRS01/06/017	Washer	18 - CRS01/06/018	Bolt
19 - CRS01/06/019	Support bracket	20 - CRS01/06/020	Rear Panel
21 - CRS01/06/021	Rear Frame	22 - CRS01/06/022	Bearing 6205ZZ
23 - CRS01/06/023	C. Retainer ring R-52	24 - CRS01/06/024	Up Roller Sprocket
25 - CRS01/06/025	C. Retainer ring S-70	26 - CRS01/06/026	Up Roller Tension Spring
27 - CRS01/06/027	Connecting Board	28 - CRS01/06/028	Up Roller Cam
29 - CRS01/06/029	Motor Sprocket	30 - CRS01/06/030	Sprocket
31 - CRS01/06/022	Bearing 6205ZZ	32 - CRS01/06/032	Sprocket
33 - CRS01/06/033	Motor (110/220V)	34 - CRS01/06/034	Conveyor Belt
CRS01/06/033A	Centrifugal Governor	CRS01/02/034A	Conveyor Belt (Flat)
CRS01/06/033B	Centrifugal Switch	CRS01/02/034B	Conveyor Belt (Ridges)
CRS01/CAP/STA	Start Capacitor	CRS02/02/034A	Conveyor Belt (Flat)
CRS01/CAP/RUN	Run Capacitor	CRS02/02/034B	Conveyor Belt (Ridges)
CRS01/06/035	Tension Screw	CRS01/06/036	Left Support Bracket
CRS01/06/037	Right Support Bracket	CRS01/06/038	Extension Catch Tray

BakeMax Part #	Part Description	BakeMax Part #	Part Description
39 – CRS01/06/039	End Roller Complete	40 – CRS01/06/040	C. Retainer Ring S-20
39 – CRS02/06/039	End Roller Complete		
41 – CRS01/06/041	Bearing 6004ZZ	42 – See #39	Roller Shaft - N/A
43 – CRS01/06/043	Outfeed Table	44 – CRS01/06/044	Connecting Rod
45 – CRS01/06/045	Left Support Bracket	46 – CRS01/06/046	Right Support Bracket
47 – CRS01/06/047	Base	48 – CRS01/06/048	Bearing Block
49 – CRS01/06/049	Bearing 6003ZZ	50 – CRS01/06/050	Thrust Bearing 51203
51 – CRS01/06/051	Drive Roller BMCRS01	52 – CRS01/06/052A	Bearing Block (Flat Belt)
51 – CRS02/06/051	Drive Roller BMCR02	52 – CRS01/06/052B	Bearing Block (Ridge Belt)
53 – CRS01/06/053	Support Axle	54 – CRS01/06/054	Nut
55 – CRS01/06/055	Sliding Seat	56 – CRS01/06/022	Bearing 6205ZZ
57 – CRS01/06/057	Up roller	58 – CRS01/06/058	Bolt
59 – CRS01/06/059	Double Scraper Rod	60 – CRS01/06/060	Link Mass
61 – CRS01/06/061	Torsion Spring (Scraper)	62 – CRS01/06/062	Double Scraper Bar
63 – CRS01/06/063	Upper Double Scraper	64 – CRS01/06/064	Double Scraper Bar
63 – CRS02/06/063	Upper Double Scraper	64 – CRS02/06/064	Double Scraper Bar
65 – CRS01/06/065	Front Frame	66 – CRS01/06/066	Roller Head Housing
67 – N/A	Stop Pin – N/A – Welded *Use Long Bolt/Screw	68 – CRS01/06/068 68 – CRS02/06/068	Safety Guard CRS01 Safety Guard CRS02
69 – CRS01/06/022	Bearing 6205ZZ	70 – CRS01/06/070	Down Roller
71 – CRS01/06/071	Lower Scraper CRS01	72 – CRS01/06/072	Bolt Support CRS01
71 – CRS02/06/071	Lower Scraper CRS02	72 – CRS02/06/072	Bolt Support CRS02
73 – CRS01/06/073	Anchor Block	74 – CRS01/06/074	Drive Roller Tension Bolt
75 – CRS01/06/075	Expansion Spring Lower Scraper	76 – CRS01/06/076	Scraper Ring

BakeMax Part #	Part Description	BakeMax Part #	Part Description
77 – CRS01/06/077L CRS01/06/077R	Microswitch Trigger Left Microswitch Trigger Right	CRS01/06/078	Microswitch (Orange Button)
79 – CRS01/06/079	Bolt	80 – CRS01/06/080	Lock Washer
81 – CRS01/06/081	Washer	82 – CRS01/06/077	Trigger – See # 77
83 – CRS01/06/083	Directional Lever Microswitch (Lever Type)	84 – CRS01/06/084	Bolt
85 – CRS01/06/085	Compression Spring	86 – CRS01/06/086	Ball
87 – CRS01/06/087	Fixed Support	88 – CRS01/06/088	Locating Mass
89 – CRS01/06/089	Movement Control Lever	90 – CRS01/06/090 90 – CRS02/06/090	Thickness Handle Shaft CRS01 Thickness Handle Shaft CRS02
91 – CRS01/06/091	C. Retainer ring S-25	92 – CRS01/06/092	Connecting Board
93 – CRS01/06/093	Graduated Scale	94 – CRS01/06/094	Arrow
95 – CRS01/06/095	Handle Base	96 – CRS01/06/096	Front Panel
97 – CRS01/06/097	Teflon Spacer	98 – CRS01/06/098	Thickness Adjustment Handle
98 – CRS01/06/098A	Handle O-Ring	101 – CRS01/06/101	Bolt Cover
102 – CRS01/06/102	Trigger Pin	103 – CRS01/06/103	Compression Spring
104 – CRS01/06/104	Trigger Locking Lever	105 – CRS01/06/105	Knob
106 – CRS01/06/106	Rail Rest	107 – CRS01/06/107	Bolt
109 – CRS01/06/109	Internal Half of Handle	110 – CRS01/06/110	External Half of Handle
111 – CRS01/06/111	Cap Screw M6	112 – CRS01/06/112	Handle Locking Assembly
113 – CRS01/06/113	Locating Mass		













