



# BakeMax BMPM020

1	TOP COVER	48	BALL	133	BOLT
2	MAIN SHAFT COVER	49	SHIFTER FIXED SHAFT	134	BOLT
3	OIL BAFFLE	50	SHIFT FORK	135	MACH SCREW
4	GEAR HOUSING COVER	51	SHIFT FORK PLUNGER	136	SCREW
5	HEAD	52	COMPRESSION SPRING	137	SET SCREW
6	COVER OF BACK HEAD	53	SCREW	138	SET SCREW
7	SHAFT COVER	54	19T GEAR	139	SCREW
8	CONTROL PANEL	55	63T INTERNAL GEAR	140	WASHER
9	CONTROL PANEL	56	HEAD RING	141	C-TYPE SNAP RING R47
10	AGITATING SHAFT	57	PLANETARY HEAD	142	WASHER
11	DETAIN-FIXED COVER	58	AGITATING SHAFT	143	SPRING WASHER
12	FLAT WASHER	59	TAPERED PIN	144	SPRING WASHER
13	46T GEAR	60	COLUMN	145	SPRING WASHER
14	SLEEVE DRIVE	61	BASE	146	SPRING WASHER
15	BEVEL GEAR(46T)	62	REAR COVER	147	NUT
16	29T GEAR	63	SEAT OF CONTACTOR	148	NUT
17	CLUTCH COPPER BUSHING	64	SEAT OF LIMIT SWITCH	149	NUT
18	CLUTCH	65	COVER OF LIMIT SWITCH	150	NUT
19	38T GEAR	66	BOWL SUPPORT	151	NUT
20	WASHER	67	BOWL SUPPORT LOCKING BAR	152	CAP SCREW
21	SPACER	68	BOWL PIN	153	MOTOR SHAFT
22	PIN	69	BOLT 1/4*2	154	WASHER
23	SPRING SHEET	70	BOWL FIXED PLATE	155	刮刀座蓋
24	15T GEAR SHAFT	71	LIFTING BAR	157	C-TYPE SNAP RING S20
25	32T GEAR	72	LIFTING HANDLE BRACKET	158	C-TYPE SNAP RING S20
26	23T GEAR	73	LIFTING HANDLE	159	C-TYPE SNAP RING R40
27	OIL BAFFLE	74	COMPRESSION SPRING	160	壓縮彈簧
28	WORM GEAR SHAFT	75	BOWL	161	把手柄球
29	WORM GEAR (26T)	76	REDUCTION BOWL	162	固定軸
30	OIL BAFFLE	77	BEATER	163	刮刀柄(卸式)
31	五爪蝸桿-50HZ用	78	REDUCTION BEATER	164	刮刀片(卸式)
32	SPACER	79	HOOK	165	BBER COVER FOR BOWL SUPPC
33	ROTOR OF MOTOR	80	REDUCTION HOOK	166	FOOT COVER-FRONT
34	STATOR OF MOTOR	81	WHIP	167	FOOT COVER-BACK
35	BEARING HOUSING	82	REDUCTIO WHIP	168	C-TYPE SNAP RING S16
36	BEVEL GEAR (35T)	83	SAFETY GUARD FIXED SHEET	169	HOLE COVER
37	OIL BAFFLE	84	SAFETY GUARD ACTIVE SHEET	170	O RING
38	HUB ATTACHMENT	85	FIXED RING		GROMMET
39	ATTACHMENT HOLE PLUG	86	EMERGENCY STOP		
40	BOLT	87	GREEN BUTTON		
41	HANDLE BALL	88	TIMER		
42	HANDLE ARM		TIMER KNOB		
43	ECCENTRIC SHIFT SHAFT		GREEN RECTANGLE BUTTON		
44	SHIFT SELECTOR		RED RECTANGLE BUTTON		
45	ECCENTRIC SHAFT		START CAPACITOR-110V		
46	COMPRESSION SPRING		TERMINAL		
47					
48					
49					
50					
51					
52					
53					
54					
55					
56					
57					
58					
59					
60					
61					
62					
63					
64					
65					
66					
67					
68					
69					
70					
71					
72					
73					
74					
75					
76					
77					
78					
79					
80					
81					
82					
83					
84					
85					
86					
87					
88					
89					
90					
91					
92					
93					
94					
95					
96					
97					
98					
99					
100					
101					
102					
103					
104					
105					
106					
107					
108					
109					
110					
111					
112					
113					
114					
115					
116					
117					
118					
119					
120					
121					
122					
123					
124					
125					
126					
127					
128					
129					
130					
131					
132					
133					
134					
135					
136					
137					
138					
139					
140					
141					
142					
143					
144					
145					
146					
147					
148					
149					
150					
151					
152					
153					
154					
155					
156					
157					
158					
159					
160					
161					
162					
163					
164					
165					
166					
167					
168					
169					
170					